


System start



How to turn on the system

Tap the button according to your use case.

Local mode - Use AV system locally


VC mode - Use AV system with Cisco/Zoom video conference

*Blu-ray player can not be used in this mode

The wait screen will be displayed during the system startup.

The main screen will be displayed once system has booted completely.

/ Displays



Local mode

Switch pages with the tabs.

Tap the button next to the source you wish to display.

Preview : The preview monitor in front of the control desk

Screen : Main projector screen

(highlighted screen source will change as the display changes)

Adjust the source / microphones volume.




Turn down the volume




Turn up the volume




Mute On / Off : That will turn red () while muted.

*Fine tune volumes using the BOSE volume controller on the desk if necessary.

Shutdown system



How to shutdown the system


Tap the power button () at the bottom of the screen.

The confirmation message will appear on the screen.

Tap  to shut down.


Tap  to cancel.





Local mode – Blu-ray

You can control Blu-ray player remotely in this tab while in Local mode.




How to control lighting


This tab can control lighting in the Auditorium.

Hall : Main lighting in the room

Stage Spotlights : Spotlights for the front area

***Turn up the "Green fader" on the lighting controller to use spotlights.**






■ Settings

You can switch between Local/VC modes.

*The system will reset to default settings when you switch modes.



■ VC mode – Share Content

- Switching the shared content source during the video conference with participants.

Select the device to share the screen with participants.