


How to use the Projector in C600a/b

- 1** Connect your PC to the VGA, or HDMI* cable.
*Use the appropriate adapter if necessary.
- 2** Press the **ON** button on the remote control.
- 3** Press the input button corresponding to the input source (VGA or HDMI).



DO NOT LEAVE THE PROJECTOR ON

Press the **STANDBY** button on the remote control to turn the projector off.

Please do not change any other settings on the projector. If you require custom settings, please restore any changed settings back to the previous state after usage.

Contact AV Services at av@oist.jp or 11534, to request assistance or report a fault.