


How to use the Projector in SH Seminar

1 STEP ONE

CONFIRM THE AV RACK IS POWERED ON

Press the **System Power** button on right side of the AV Rack.



2 Press the **ON** button on the projector remote control and tap the touch screen to wake up the system.

3 Press the **HDBaseT** button on the remote control after PJ is powered.

4 Connect your PC to HDMI* cable at podium.
**Use the appropriate adapter if necessary.*




Troubleshooting

➤ No Image on screen?

- Unplug and reconnect the video cable to your laptop, ensuring it is firmly connected.
- Confirm "HDBaseT" input source on projector remote.
- Confirm "Podium HDMI" channel is selected on the video switcher.
- If using VGA, confirm "VGA PC Input" channel is selected on the video switcher.

➤ No Sound from PC Source or Mic?

- Confirm Speaker device on your PC.
- Confirm the volume level for the SOURCE input on the mixer located at the AV Rack.
- Confirm mic volumes on mixer at AV Rack – adjust lower if you are getting distortion or feedback.



PLEASE TURN OFF SYSTEM AND PROJECTOR

Press the **STANDBY** button on the remote control to turn off the projector.

Contact AV Services at av@oist.jp or 21534, to request assistance or report a fault.